

UNIVERSAL SILICONE

DATA SHEET 01/2016

DESCRIPTION:

One part, acetic curing, silicone rubber based sealant.

PROPERTIES:

One component room temperature vulcanising (RVT), easy application system. Cures in contact with air humidity, and turns into a rubber with outstanding mechanical properties and excellent weatherability.

APPLICATIONS:

High-performance sealant for:

- Sealing joints between glass and frameworks and joints between frameworks.
- Do it yourself (DIY).

Due to its acid reticulation, UNIVERSAL SILICONE must not be applied on the folowing substrates:

- Construction materials such as concrete, masonry, marble and similar.
- Ferrous metals, copper, and brass.
- Rubber, since there may be a danger of discolouration.

For these cases QUILOSA markets a wide a range of non-acid sealants.

CERTIFICATIONS:

CE Mark: EN15651-2 G-CC / EN15651-3 S Dop nº: SIB0000178 http://ce.selena.com/

TECHNICAL FEATURES

Appearance:	Homogeneous creamy paste		
Slump resistance (ISO 7390):	mm	0	
Tack free (ASTM C-679-71):	minutes	10 – 15	
Skin over time (BS 5889 Ap.A):	minutes	25 – 35	
Curing rate at 23° C And 55% h.r.:	mm/day	2 – 3	
Application temperature:	°C	+5 to +50	

CURED UNIVERSAL SILICONE (4 weeks at 23^oC and 55^o H.R.)

(4 weeks at 25°C and 55 /0 m.N.)				
Appearance:	Similar	Similar to rubber.		
Shore a hardness	-	14 <u>+</u> 2		
(ISO 868):				
Elastic recovery	%	96		
(ISO 7389):				
Modulus 100%	Mpa.	0,33 – 0,36		
(ISO 37):				
Tensile strength	Mpa.	1,20 – 1,40		
(ISO 37):				
Elongation at break	%	350 - 500		
(ISO 37):				
Movement accomodation factor:	%	20		
Temperature range in service:	°C	-50 to		
		+150		





UNIVERSAL SILICONE

DATA SHEET 01/2016

CHEMICAL RESISTANCE:

Water, soapy water, brine: Inorganic diluted acids and alkalis: Mineral oils and grease: Oil, fuel, hydrocarbons: Other products: Excellent. Very good. Very good. Very good. Consult.

INSTRUCTIONS:

Treatment of joints:

The surfaces to be sealed must be clean and dry. If necessary, in addition to mechanical treatment, cleaning with non-grease solvent such as acetone is recommended. For joints to be subjected to major stress, we suggest the use of a primer appropriate for each type of substrate:

PRIMER	C-27:	For	porous	materials	and	general
	0.00		struction		_ 4' _ ! _	
PRIMER	6-29:	For plasticized or unplasticized PVC polyacrylates and other plastics.		,		
(See Data)	technical	р <i>с.</i> ј	acijiatoo		process	

With glass and enamels, better results are obtained without primer.

Any material not known by the user in terms of adhesion must previously be tried out or consulted with our Technical Department.

Procedure:

Cut off cap from adapter nipple, screw the nozzle on the cartridge, clip the tip of the nozzle to required opening and insert into caulking gun. Fill in the appropriately treated joint with **UNIVERSAL SILICONE**. In order to avoid messing the edges, they may

be protected with masking tape. For a better finish, the seal may be smoothed with a spatula.

Yield

The following formula is an approximate guideline in order to calculate foreseen yield for a standard cartridge of **UNIVERSAL SILICONE**:

$$L = \frac{300}{A \times D}$$

Where:

- L= Length of sealant in metres obtained per cartridge of UNIVERSAL SILICONE.
- A= Width of the joint in mm.
- D= Depth of the joint in mm.

Further treatment:

UNIVERSAL SILICONE may not be painted or varnished.

STORAGE:

Keep in a cool and dry place. Lifetime: 12 months in original sealed container.

PRESENTATION:

Cr 300 cc. Plastic cartridges. 24 cartridges boxes.

COLOURS:

Translucent Aluminium White Bronze Grey Black Green

Others colours on order

LIMPIEZA:

Fresh product is easily removed with an organic solvent. When cured it can be removed by mechanical mean only



Quilosa - Selena Iberia S.L.U. Centro empresarial Rivas Futura, C/ Marie Curie 19, Planta 6.1, 28521 Rivas, Madrid, Spain, Tel: +34 902 02 18 02 – Fax: +34 914 999 796, info@quilosa.es, www.quilosa.com



UNIVERSAL SILICONE

DATA SHEET 01/2016

HEALTH & SAFETY

While curing **UNIVERSAL SILICONE** splits off acetic acid, therefore, the working area should be well ventilated

Due to possible irritation, all contact of the product with eyes or mucous areas must be avoided. If this should occur, rinse the affected area thoroughly with plenty of water and, if need be, see a doctor. Rubber resulting after curing may be handled without risk.

Primers used with **UNIVERSAL SILICONE** contains flammable solvents at room temperature. Do not smoke or use unprotected flame near the working area. If eyes are splashed, rinse thoroughly with plenty of water, otherwise, see a doctor.

Use gloves, and in case of splashing, wash with industrial detergent when the product is still fresh. **DO NOT WASH HANDS WITH SOLVENTS.**

For more information request Safety Data Sheet.

""The information contained herein is offered in good faith based on Selena's research and is believed to be accurate. However, because conditions and methods of use of our products are beyond our control, this information shall not be used in substitution for customer's tests to ensure that Selena's products are fully satisfactory for your specific applications. Selena's sole warranty is that the product will meet its current sales specifications. Your exclusive remedy for breach of such warranty is limited to refund of purchase price or replacement of any product shown to be other than as warranted. Selena FM S.A. specifically disclaims any other expressed or implied warranty of fitness for a particular purpose or merchantability. Selena disclaims liability for any incidental or consequential damages. Suggestions of use shall not be taken as inducements to infringe any patent.

Technical indications and data appearing in this brochure are based on our current knowledge and experience and we decline all responsability for consequences derived from inadequate use. Therefore, our guarantee is limited exclusively to the quality of the product supplied. This technical information can be modified without notice. If necessary request it periodically."



Quilosa - Selena Iberia S.L.U. Centro empresarial Rivas Futura, C/ Marie Curie 19, Planta 6.1, 28521 Rivas, Madrid, Spain, Tel: +34 902 02 18 02 – Fax: +34 914 999 796, info@guilosa.es, www.guilosa.com