



# Hi-Temp Red Silicone

## Technical Data Sheet

Rev 01/22

**PRODUCT DESCRIPTION:** Hi-Temp Red Silicone is a high performance, single component, moisture curing RTV (room temperature vulcanizing) silicone gasketing material that cures into a strong, silicone rubber that maintains long term durability and flexibility. Hi-Temp Red Silicone is a non-slumping, paste-like consistency which cures when exposed to moisture in the air. Excellent for filling gaps, use for sealing, bonding weatherproofing and caulking applications. Forms a tough, flexible silicone rubber gasket that resists aging, weathering; will not harden, shrink or crack.

**WORKS BEST ON:** Use to replace gaskets on valve covers, water pumps, oil pans, rear end covers, thermostat housings, timing gear covers and wherever you need a leak-proof gasket.

*(OEM Approved = Original Equipment Manufacturer Approved)*

### PRODUCT FEATURES:

Tensile Strength: 310 psi

Non-Flammable

Low Volatile, Oxygen Sensor Safe

Color: Red

Water Resistant

Set Time: 8 – 10 Minutes

Full Bond: 12 – 24 Hours (Cure times will vary with temperature, humidity and gap)

Temperature Range: -65°F (-54°C) to 650°F (343°C)

Chemical Solvent Resistance: oil, water and antifreeze mixtures

**NOT RECOMMENDED for use on parts in constant contact with gasoline. Do not use on head gaskets or around carburetors.**

Storage: Store in a cool, dry environment.

**SURFACE PREPARATION:** Protect work area from accidental spills. Clean surface with a residue-free solvent to remove grease, oil, dirt or other contaminants.

**REMOVAL METHODS:** (test inconspicuous area of item to be sure chemicals do not harm surface)

**Before cure:** Scrape off excess with a knife or non-flammable cleaning fluid. If skinned over, break film with a dry cloth and remove as much as possible. Remove any remaining material with a gasket remover.

**After cure:** Scrape or peel off, then solvent clean surface.

**HELPFUL HINTS:** Clean and dry surfaces thoroughly. Apply a thin even bead (1/8") to one surface. Wait 10 minutes until sealant skins before assembling. For temporary assemblies, apply a light coat of oil to uncoated surfaces, then assemble. Clean excess with a knife. Replace cap after use. Sealant is fully cured in 12-24 hours.

Higher humidity accelerates the cure of the silicone adhesives. Parts should be mated and the sealants worked (tooled) before the adhesive surface "skins over" or becomes tack free, normally within 30 minutes at 50% relative humidity and 75°F.

For storage: after use, create a silicone plug by pushing excess material to extend beyond the extension nozzle and allow to cure (this will seal and protect unused product). To reuse, simply remove the cured "plug" from tip.

Note, the curing process of High Temp Red Silicone can cause corrosion to some surfaces, For critical applications refer to our Mega Silicones, which are non-corrosive, low odor and low volatile.

**See MSDS for more complete information, safe handling instructions and first aid.**

Non-Regulated

Part Number(s): 65309



The technical data contained herein are intended as a reference only