



PRODUCT TECHNICAL INFORMATION

Engine

Head Gaskets & Seals

Transmission

Power Steering

Cooling System

Bar's Manual Transmission Stop Leak

As engines accumulate kilometers, its components begin to wear with age and repetitive use. It is not uncommon for the seals and gaskets to become warped and cracked because of extremes in both temperature and pressure. The result is leaking seals and gaskets which keep vital fluids inside the transmission.

Description:

Bar's Manual Transmission Stop Leak is specially formulated to restore worn seals and gaskets in order to stop transmission fluid leaks.



Manual Transmission Stop Leak
200 mL

Directions:

Add contents of bottle to the transmission in order to restore the fluid level. Typically, 320-480 kilometers of driving must be done before leaks will stop. If the leak persists, a second bottle may be required. One bottle will typically treat up to 4 liters of gear lube.

NOTE: Mechanical attention may be necessary if leaks continue after treatment.

Benefits:

- 🔥 Stops transmission fluid leaks
- 🔥 Restores worn and dried out seals & gaskets
- 🔥 Compatible with all transmission fluids

Warnings:

The transmission sump should never be overfilled. Check fill level before and after application of **Bar's Manual Transmission Stop Leak**. Always be careful when working on an engine or its components as engine components can be hot and cause severe burns.

Physical Characteristics:

Physical state: Liquid
Color: Red
Odor: Characteristic
pH: N/A
Vapor pressure: @20°C: Not Known
Vapor density (air = 1): >1
Solubility: Not Soluble
Freezing point: Not Known
Specific gravity: 0.855 g/mL
Flash point: >100°C

